


**_Keyboard**

Octave Transpose
Semitone Transpose
Reset Transpose
Set Split Point

_Arpeggiator

Arp On/Off
Arp Hold
Arp Settings
Assign Arp to Part 1/2

_Chord / Scale

Chord On/Off
Scale On/Off
Chord Settings
Custom Chord
Assign Chord to Part 1/2

_Recorder / Looper

Play / Stop Recording
Record
Set / Tap Tempo
Metronome On/Off
Recording Settings
Panic

Oct- / Oct+
Shift + Oct-/Oct+
Oct- + Oct+
Split + Keyboard Key

Short press Arp
Shift + Arp
Long press Arp
Part 1/2 + Arp

Short press Chord
Shift + Chord
Long press Chord
Hold Chord + Keyboard keys
Part 1/2 + Chord

Short press ►
Short press ●
Shift + ►
Shift + ●
Long press ●/►
Long press ► + ●

_Navigation

Navigate Presets or Menus
Select Preset or Menu
Select Previous Preset or Menu
Select Next Preset or Menu
Edit Preset or Menu

Go to previous screen
Go to Home screen
Panic

_Sound edit

Enter Sound edit
Add a Part to a Single Preset

Enter Part Sound edit

_Multi-Instrument control

Control a Part's Macros
Edit a Part
Edit Part MIDI Settings

Turn Wheel
Press Wheel
↑
↓
Shift + Press Wheel
or Long Press Wheel
Back
Shift + Back
Shift + ↑ + ↓

Select Sound Edit
in Edit Menu
Short Press Part 2
then Press Wheel
Short Press Part
then Press Wheel

Short press Part 1/2
Shift + Part 1/2
Shift + Split

_Master Control

Set Preset Volume
Set Master Bass
Set Master Mid
Set Master Treble

_Preset buttons

Filter all Presets by Type
Filter the current list by Type
Open/Close current Playlist
Save current Preset

_Effects control

Set FX A Intensity
Set FX B Intensity
Activate FX A/B/Delay/Reverb
Edit FX A/B/Delay/Reverb
Assign FX A/B to Part 1/2
Set Delay Time
Set Reverb Decay

Shift + Brightness
Shift + Timbre
Shift + Time
Shift + Movement

Short press Preset buttons
Long Press Preset
buttons
Playlist
Shift + Playlist

Shift + FX A
Shift + FX B
Short press ◐
Long press ◐
Part 1/2 + ◐
Shift + Delay
Shift + Reverb